

82 AirDam Installation Instructions

1. Loosely bolt AirDam assembly together the left and right sides will be behind the front
2. use provided 3/8" x 1" button head bolts with washers.
NOTE The bolts need to be tight enough to hold the assembly together but loose enough they can still slide in the slots.
3. Place whole assembly on to trailer. Make sure the angles are sitting on top of the the top rail.
NOTE You will either need to clamp the angles to the top of the front rail or have another person hold it.
4. Mark and drill the 7 holes that hold the airdam to the top rail. 1 in each side and 5 in the front piece.
5. Bolt to the top rail with provided 3/8" x 2 1/2" button head bolts and washers and nylock nuts.
6. Tighten all bolts holding the 3 pieces together.

| Item # | Description | Qty. |
|--------|---------------------------------|------|
| 1 | 3/8" x 1" Button head bolts | 12 |
| 2 | 3/8" x 2 1/2" Button head bolts | 7 |
| 3 | 3/8" Flat Washers | 26 |
| 4 | 3/8" Nylock nuts | 7 |

